

Alarm Clock

/ GVA AV203



Instruction Manual

12
MONTH


MANUFACTURER'S
WARRANTY

GVA

THE 'V' STANDS
FOR VALUE.

ENGLISH

1. MINUTE SET BUTTON
2. TIME SET BUTTON
3. HOUR SET BUTTON
4. ALARM SET/ BUTTON
5. SNOOZE BUTTON
6. ALARM ON/ OFF SWITCH
7. BATTERY COMPARTMENT
8. LED DISPLAY
9. AC POWER Cord
10. ALARM OFF BUTTON



1. CONNECTING THE POWER

Insert correctly wired plug into a power outlet. The clock display will blink showing that the time is not correct. It will also blink if there has been a power cut and no back up battery is fitted.

2. TO SET THE TIME

- 2.1 Press and hold the Time Set Button(2).
- 2.2 Press the Minute Set Button(1) or Hour Set Button(3) to set the clock display to the correct time.
- 2.3 Release the Time Set Button(2).

3. TO SET THE ALARM TIME

- 3.1 Press and hold the ALARM SET (4) button.
- 3.2 While holding the ALARM SET (4) button press the HOUR SET (3) Button and MINUTE SET buttons (1) to advance the time until the desired alarm time is shown on the display.

NOTE: To check up the wake-up time, press the Alarm Set Button(4). The clock display will show the preset alarm time.

4. WAKE TO BUZZER ALARM

- 4.1 Set the Alarm ON/ OFF Switch(6) to ON Position. The respective AUTO indicator will light on. The buzzer will now be switched on automatically at the selected alarm time for one hour and 59 minutes
- 4.2 Press the Alarm Off button (10) to turn off the buzzer, the alarm will be activated again after 24 hours.
- 4.3 Slide the Alarm On/Off Switch (6) to deactivate the alarm function completely.

5. SNOOZE OPERATION

To obtain approximately 9 more minutes of sleep, press Snooze Set Button(5) after the Buzzer works at the preset wake-up time. This will silence the Buzzer for about 9 minutes.

6. BATTERY BACK UP

Note: The clock has a back-up power system to ensure continuous operation of the clock and alarm in the event of a power failure. The switch from AC to battery power is automatic. However, under

battery power the clock display will not illuminate even though the clock will maintain approx. The current time and will store the alarm time in its memory. The system operates on a 9V Battery (Not Included). We recommended the use of a long life battery to ensure maximum performance.

Note: This battery back-up features is intended to retain the clock time and memory functions during a power failure for short periods. The clocks should not be left for long periods of time without mains supply as the battery will drain fairly quickly. Remove the battery if the unit is disconnected from the mains.

Care: The cabinet can be dusted with soft cloth or if necessary cleaned with a soft cloth dampened with water. The power plug should be disconnected before cleaning. Never use polish, solvent, abrasives or strong detergents on the cabinet since these can damage the finish.

SPECIFICATIONS

POWER SOURCE : AC240V ~ 50Hz

Dripping warning : "The product shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the product."

Ventilation warning : "The normal ventilation of the product shall not be impeded for intended use."

- No naked flame sources, such as lighted candles, should be placed on the apparatus;
- Do not place the product in closed bookcases or racks without proper ventilation.

This product is guaranteed against faulty materials and workmanship under normal use for a period of 12 months from date of purchase.